

J5
Red = Joy2 R
Brown = Joy2 L
White = Joy2 D
Grey = Joy2 U
Purple = Ground

Orange = P2-B5 Yellow = P2-B4 Green = P2-B2 Blue = P2-B1 Purple = Ground

**J4** 


J3
Grey = P2-B7
White = P2-B3
Brown = P2-B8
Red = P2-B6
Orange = Ground

J2
Yellow = R-PB
Green = Start 2
Blue = L-PB
Purple = Start 1
Grey = Ground

J9
Purple = Switch
Blue = Switch
Orange = Switch
Yellow = Switch
Green = Switch

J8
Green = Joy1 R
Yellow = Joy1 L
Orange = Joy1 D
Red = Joy1 U
Brown = Ground

Brown = P1-B5 White = P1-B4 Grey = P1-B2 Purple = P1-B1 Blue = Ground J6 Blue= P1-B7 Green = P1-B3 Yellow = P1-B8 Orange = P1-B6 Red = Ground



J1
White = Mode B
Grey = Mode B
None
Red = LED
Brown = LED